# Stribog SP9 A3

2 - Lower receiver
3 - Bolt
4 - Barrel
5 - Upper receiver
6 - Trigger
6.2 - Trigger pin
6.3 - Trigger distance tube
7 - Hammer
7.2 - Hammer pin
7.3 - Hammer spacer
8 - Bolt catch
8.1 - Bolt chatch spring
9 - Disconector
10 - Ejector
10.1 - Ejector plate
10.2 - Ejector screw
11 - Locking roller
12.2A - Guide tube
12.2B - Guide rod
12.2C - Guide rod latch
12.2D - Guide tube bushing
12.2E - Recoil spring washer
14 - Firing pin
13 - Trigger assembly container
13.1 - Container spacer
15 - Barrel seat - front
16 - Barrel seat - rear
17 - Extractor
18 - Takedown pin - front
19 - Takedown pin - rear
20 - Magazine catch
21 - Magazine release button
21.1 - Magazine release spring
21.2 - Magazine release pin
21.3 - Magazine release distance pin
21.5 - Pin 4x20
22 - Safety lever - right
23 - Safety lever - left
24 - Barrel nut
25.1 - Charging block
25.2 - Locking rod
25.3 - Charging piece
25.5 - Locking rod block
25.6 - Pin 4x12

26 - Charging handle
27 - Barrel bushing - rear
28 - Barrel bushing - front
30 - Trigger spring
31 - Safety lever latch spring / Muzzle brake detent spring
32 - Disconector spring
33 - Hammer spring
34 - Firing pin spring
36 - Recoil spring
38 - Upper receiver endcap
40 - Extractor pin
40.1 - Extractor spring rest
42 - Recoil pad
43 - Trigger assembly pin
46 - Muzzle brake
47 - Spring pin 4x18
48 - Safety lever latch
49 - Extractor spring
52 - Takedown pin spring - front
52.1 - Takedown pin spring - rear
57 - Muzzle brake detent base
58 - Muzzle brake detent pin
59 - Muzzle brake detent
61 - Rear sight
62 - Front sight
63 - Sight spring rest
64 - Sight pin
65 - Sight spring

